


ARCHITECTURA



- Ⓛ **Montageanleitung**
- ⒼⒷ **Installation instructions**
- ⒻⓇ **Instructions de montage**
- ⒸⓃ **安装说明书**
- ⒺⓈ **Instrucciones de instalación**




< 80°C
< 176°F





~10°C
~50°F




TVT10350100061






TVS10330100061





[mm]









TVP10300402061



TVP10300402061







Änderungen vorbehalten

We reserve the right to make alterations

Sous réserve de modifications

我们保留作出改变的权利

Nos reservamos el derecho de hacer cambios
o modificaciones

Controlled


Villeroy & Boch
1748

Villeroy & Boch AG
Postfach 12 30 - 66689 Mettlach
Germany
Tel: +49 (0) 6864 816000
Fax: +49 (0) 6864 815687
www.villeroy-boch.com

Villeroy & Boch Service centre
Tel: 400-820-1748